



*Designers and Manufacturers of Mobile Health Clinics*

# ADI Technical Bulletin #4

## HWH Automatic Jacks Retraction

### UPDATED PROCEDURE

1. Past procedures may have indicated to turn OFF the jack control as soon as the RED lights go out – DO NOT FOLLOW THAT PROCEDURE.
2. The correct procedure is to press the STORE button and leave it and the ACC ignition switch on.
  - a. Turn the ignition switch to ON, ACC, or start the engine. Press the “I” (ON) button one time only. The “I” indicator light will glow steady.
  - b. Press the STORE button. The STORE indicator light will flash. As each jack retracts, its red WARNING light will go out.
  - c. The vehicle can be moved as soon as all red WARNING lights are out and the green TRAVEL light is on, providing the jacks are in the STORE/TRAVEL position.
  - d. The system MUST be allowed to finish the store mode. DO NOT interrupt power to the leveling system while the STORE indicator light is blinking. DO NOT push the OFF button or turn the ignition key.
  - e. The STORE light will go out automatically approximately six minutes after the last red warning light goes out.
  - f. If any one red WARNING light does not go out, the system will continue to store for thirty (30) minutes, then shut down regardless of the WARNING lights condition.
  - g. NOTE: Even if all the red WARNING lights are out and the green TRAVEL light is on, visual inspection to insure that the jacks are properly stored for travel is highly recommended.

#### ADI Mobile Health - FACTORY

19425 SW 89th Avenue  
Tualatin, OR 97062 USA  
[www.adi-mobilehealth.com](http://www.adi-mobilehealth.com)

Phone: +1-503-885-0886  
Fax: +1-503-885-0417  
[tech@adi-mobilehealth.com](mailto:tech@adi-mobilehealth.com)  
[sales@adi-mobilehealth.com](mailto:sales@adi-mobilehealth.com)